

Suit Sizing

- Measure *twice* to eliminate errors.
- Measure the body, movement allowances are accounted for at factory.
- The measuring tape should not be too tight and able to move around when measuring.
- To measure

1. **Neck Size** - Measure the circumference of the neck at collar position.
2. **Shoulders** - Measure horizontally between the bumps on the shoulder bones.
3. **Chest** - Measure just beneath the armpits with arms held out horizontally. (for bust measurement measure over and just under the bust)
4. **Waist** - Measure around the waist at the navel.
5. **Seat** - Measure around the widest area of the hips.
6. **Outside Arm** - Measure with arm bent at 90° from wrist bone to shoulder bone.
7. **Outside Leg** - Measure from ankle bone to hip bone.
8. **Inner Leg** - Measure from ankle bone to crutch.
9. **Back** - Measure down back from bottom of collar, the bony bump at the base of the neck, to the waist at navel height.
10. **Thigh** - Measure thigh circumference, 12cm down from crutch.

Suit Sizes		XXS	XS	S	M	L	XL	XXL	XXXL
1	Neck	44	45	46	47	48	49	50	51
2	Shoulders	40	42	44	46	48	50	52	54
3	Chest	84	90	96	102	108	114	120	126
4	Waist	79	85	91	97	103	108	114	120
5	Seat	86	92	98	104	110	116	122	128
6	Outside Arm	57	59	61	63	65	67	69	71
7	Outside Leg	90	93	96	99	102	105	108	111
8	Inner Leg	68	71	74	77	80	83	86	89
9	Back	47	48	49	50	51	52	53	54
10	Thigh	44	48	52	55	58	61	64	68

RPM SUIT SIZING INFORMATION

MEASUREMENTS IN CM